

eCorect® Quick List

Check Shaft Rotation:

Looking at side electrical panel



Clockwise rotation for EMPTY



Counter-clockwise rotation for NORMAL operation

Check drain line:

Make sure line is not kinked, damaged, or obstructed in any way.

The drain line is a gravity drain; it *CANNOT* be placed into a bucket. Make sure drain line is no higher than the drain exit point on machine.

Check all keys:

Make sure all keys work in all locks.

Check Electrics:

Make sure all LCD displays are functioning.

Check Clearance:

Make sure unit is placed *NO CLOSER* than 8” from a wall. Proper air circulation is required.

Clean Air filter:

EVERY CYCLE!

Clean Gasket Areas:

EVERY CYCLE